



A1	LH Receiver Plate Semi	F4	Bolt Catch Block	J6	Safety Stop Bar Screw
A2	RH Receiver Plate Semi	F5	Bolt Lock	J7	Semi Disconnect
A3	Receiver Plate Spacer	F6	Bolt Lock Pin	J8	Plunger
A4	Receiver Plate Rivet	F7	Bolt Lock Spring	J9	Semi Plunger Spring
A5	Receiver Plate Screw	F8	Bolt Lock Shim	J10	Plunger Set Screw
A6	Short Receiver Screw	F9	Bolt Lock Screw	J11	Hammer Semi
B1-1	.45 ACP Barrel	G1-1	.45 ACP Bolt	J12	Hammer Spring
B1-2	9x19mm Barrel	G1-2	9mm Bolt	J13	Primary Sear Spring
B1-3	9x21mm Barrel	G2-1	.45 ACP Firing Pin	J14	FCG Spacer LH
B2	Trunnion	G2-2	9mm Firing Pin	J15	FCG Spacer RH
B3	Barrel Pin	G3	Firing Pin Spring	J16	Hammer Spacer
B5-1	.45 ACP Thread Protector	G4	Firing pin Retaining Pin	K1	Pivoting Trigger
B5-2	9mm Thread Protector	G5-1	.45 ACP Extractor	K2	Pivoting Primary Sear
C1-1	.45 ACP Ejector Mount	G5-2	9mm Extractor	K3	Trigger Spring Stop Screw
C1-2	9mm Ejector Mount	G6	Extractor Spring	K4	Pivoting Trigger Spacer LH
C2-1	.45 ACP Ejector	G7	Extractor Pin	K5	Pivoting Trigger Spacer RH
C2-2	9mm Ejector	H1-1	.45 ACP Slider	K6	Trigger Sear Connector Pin
C3	Ejector Pin	H1-2	9mm Slider	M1	Folding Stock
C1-1	.45 ACP Ejector Mount	H2	Buffer	M2	Stock Latch
C1-2	9mm Ejector Mount	H3-1	.45 ACP Main Spring	M3	Stock Latch Spring
C2-1	.45 ACP Ejector	H3-2	9mm Main Spring	M4	Stock Latch Pin
C2-2	9mm Ejector	H4	Main Guide Shaft	M5	Butt Stock
C3	Ejector Pin	H5	Spring Washer	M6	Cheek Weld
D1	Charging Slider	H6	Main Guide Shaft Screw	M7	Butt Stock Screw
D2	Charging Handle	H7	Spring Plate	P1	M4 Stock Adapter
D3	Charging Slider Spring	H8	Main Guide Rod Retainer Pin	P2	Pistol Butt End
D4	Charging Handle Spring	I1	Upper Housing	P3	Locking Screw
D5	Charging Handle Pivot Pin	I2	Nose Piece	P4	QD Sling Swivel
D6	Charging Slider Spring Retainer	I3-1	.45 ACP Ejection Port	Q7	Fixed Stock Post
E1-1	.45 ACP Lower Housing	I3-2	9mm Ejection Port	Q8	Large Rivet
E1-2	9mm Lower Housing	I4	Locking Key		
E2	Magazine Catch	I5	FCG Screw		
E3	Magazine Catch Spring	I6	Upper Picatinny Rail		
E4	Magazine Catch Button	I7	Nose Piece Screw		
E5	Magazine Catch Screw	I8	Safety Lever LH		
E6	Charging Handle Spring Post	I9	Safety Lever RH		
E7	Lower Picatinny Rail	I10	Safety Lever Screw		
E8	Rail Pin	J1	Fire Control Group Frame Semi		
E9	Break Down Pin	J2	Large Dowel Pin		
F1	Bolt Lock Trigger	J3	Small Dowel Pin		
F2	Bolt Lock Trigger Pin	J4	Safety Cam		
F3	E-Clip	J5	Safety Stop Bar		